



NAVIK 200 GNSS RECEIVER



User Guide

Version – 1.0
February 2022

Contents

1 Introduction	3
1.1 About the Receiver	3
1.2 NAVIK 200 Receiver Parts List	3
1.2.1 Basic Supply kit	4
2 Setting up the Receiver	5
2.1 Front Panel	5
2.2 Bottom Panel	5
2.3 Power Supply	6
2.4 Pole-Mounted Setup	6
3 General Operations	7
3.1 Button Functions	7
4 Real-Time Kinematic Survey (RTK)	9
4.1 Installation of GEO Master	10
4.2 Connect Bluetooth to the Device	10
4.3 Start a New Project	11
4.4 Start Base Station by GEO Master	12
4.4.1 Auto Base Setup	13
4.4.2 Manual Base Setup	18
4.5 Start Rover Station by GEO Master	19
5 Internal GSM	20
6 Basic Survey Functions	21
6.1 Topo Survey	21
6.2 Auto Survey	24
6.3 Stake Points	26
6.4 PPK	28
6.5 Static	29
7 Site Calibration	31
8 Area Calculation and COGO	32
9 Data Export/Import	34
9.1 Import	34
9.2 Export	35
10 Internal Radio Mode	35
11 External Radio	37

1 Introduction

The **NAVIK 200 GNSS Receiver User Guide** is aimed to help you get familiar with the NAVIK 200 Receiver and start your project efficiently. We highly recommend you to read this manual before start surveying.

1.1 About the Receiver

NAVIK 200 GNSS Receiver can be used in static, post processed kinematic (PPK)/rapid static and RTK mode with all available GNSS constellations. NAVIK 200 Receiver has a compact size and strong anti-interference ability, making it possible to work even in different GPS environments. It is an ideal RTK/GNSS product for surveyors.


1.2 NAVIK 200 Receiver Parts List

This section provides the overall NAVIK 200 receiver parts list, including standard supply kit and customized kits based on your requirements.

1.2.1 Basic Supply Kit

NAVIK 200 GNSS Receiver Basic Supply kit contains one receiver and related accessories.

1. GNSS Receiver	
2. RF Antenna	
3. Data Collector & Tablet	
4. Download Cable	
5. Adapter	



2 Setting Up the Receiver

This chapter provides general information on the setup, power supply, and connection of the NAVIK 200 receiver.

2.1 Front Panel

The receiver's front panel has six indicator LEDs, and a Power button. The indicator LEDs show the Status of Battery, Satellite Tracking, Differential Data, Communication (Radio/ GSM), Bluetooth, and Data Logging.



2.2 Bottom Panel

The receiver's bottom panel contains a serial port (LEMO connector), a UHF radio antenna connector, a SIM card slot, and a threaded insert.

2.3 Power Supply

The receiver is equipped with an internal LI-ion battery pack with a high capacity of 6800 mAh. Its operating time depends on user behaviour and also environmental conditions. Please obey the following instructions when charging your device:

- Charge the device completely before using it for the first time.
- At room temperature, Fully charging takes approximately 5-6 hours.
- Recharge the device at least once a month if it is to be stored for a long time.

The receiver is connected to an external power supply through the



cable provided.

2.4 Pole-Mounted Setup

Mounting of receiver on a range pole is as per the figure shown below:



- Screw the receiver onto the range pole.
- Mount the controller bracket to the pole.
- Put the controller into the bracket.


3 General Operations

This chapter introduces all controls for the general operation, including button functions and all LED behavior on the front panel.

3.1 Button Functions

Power Button: Press the power button for about 2 seconds to turn on the receiver; to turn off the receiver, long press the power button (2 seconds). The receiver will go into power off mode. During this time, the receiver will beep 5-6 times and the pattern will be displayed on LEDs. This process will take about 30 seconds.

LED Behavior: The LEDs on the front panel indicate the receiver's working status. Generally, a lit or slowly flashing LED indicates normal operation, and an unlit LED indicates that no operation is occurring. The following figure defines each possible LED state:



LED	States	Indicates
 Battery LED	Battery Low	Blinks five times every second
	Normal Operation	OFF
	Charging	Blinks every second
	Full Charge	Remains in a solid state
 Satellite	Tracking	Blinks five times every second

	No Tracking	Remains in a solid state
 Differential Data	Transceiving Data	Blinks once per second
 Communication (Radio/GSM)	Radio	Blinks every second
	GSM/4G	Blinks, depending on the data transceiving frequency
	Wi Fi	Blinks every second
	RS 232	Blinks every second
	If not configured	Off
 Bluetooth	Connected	Remains in a solid state
	Disconnected	Blinks every second
 Data	Static	Solid until data log stops
	PPK	Solid until device is restarted
 Power	Long press of the key, turning on/off the NAVIK 200 Receiver	

4 Real-Time Kinematic Survey (RTK)

This chapter introduces how to conduct RTK Surveys with the Geo Master app, including software installation, starting a new project,

receiver connection, and RTK working modes (Radio and GPRS).

4.1 Installation of GEO Master Application

We can download the GEO Master app from the download center tab of the company section of the website www.apogeegnss.com. In this tab, from the app heading, you can download the latest version of the Geo Master app.

4.2 Connect Bluetooth to the Device

To build the Bluetooth connection between your GEO Master App and GNSS Receiver, it is mandatory to turn on the Bluetooth and location of your data collector.

Click Connection Type -> select Bluetooth Device -> click Connect to connect the data collector to the device.



4.3 Start a New Project

Click Select to go into the Project interface to create or select a project. For detailed information, Click + icon -> write down project name -> select datum from the predefined section inside the datum store -> make the code list -> select elevation -> enter operator name and comment (comment is optional).



The screenshot shows a 'Create' form with the following fields and values:

- Project:** 20220906_143436
- Datum:** WGS84 (selected via radio button)
- Code List:** 123
- Elevation:** Ellipsoid Height
- Operator:** Shalu
- Comment:** Testing - not mandatory

An 'OK' button is located at the bottom right of the form.


4.4 Start Base Station by GEO Master

Firstly, build Bluetooth connection between the NAVIK 200 receiver and your controller. Secondly, modify parameters including correction format, antenna type and communication protocols. We can set up two types of bases. The first is Auto base, and the second is manual base:





4.4.1 Auto Base Setup

After setting up communication -> setting up Antenna Height -> setting up auto base -> setting up corrections (such as RTK by internet, Wi-Fi, and radio)





Set up corrections -> RTK by Internet



Set up corrections -> RTK by Wi-Fi



Set up corrections -> RTK by Radio



4.4.2 Manual Base Setup

Set up Manual Base -> set parameters by UTM or Degree values -> Set up Correction format by Internet, Wi-Fi, and Radio as in Auto Base.

The screenshot shows the 'Parameters' screen with the 'UTM' mode selected. The fields are: Mask-angle (10), Latitude (29.28537), Longitude (72.14523), and Altitude (164). There is an 'OK' button at the bottom.

Parameter	Value
Mask-angle	10
Latitude	29.28537
Longitude	72.14523
Altitude	164

The screenshot shows the 'Parameters' screen with the 'DEGREE' mode selected. The fields are: Mask angle (5), Easting (732762.613), Northing (3168174.565), Elevation (172.507), and Zone (43.0). There is an 'OK' button at the bottom.

Parameter	Value
Mask angle	5
Easting	732762.613
Northing	3168174.565
Elevation	172.507
Zone	43.0

The screenshot shows the 'GNSS Base Profile' screen. It displays: Make Apogee, Model NAVIK200, NAVIK200-1.1_00035, Antenna Height 2 m, and Basic Parameters. There are 'SET UP CORRECTIONS' and 'DONE' buttons.

Field	Value
Make	Apogee
Model	NAVIK200
Model ID	NAVIK200-1.1_00035
Antenna Height	2 m
Basic Parameters	


Now set up correction formats like in auto base to start the base station manually.

4.5 Start Rover Station by Geo Master

- GEO Master connects via Bluetooth to the NAVIK 200 receiver.
- Set the same protocol and frequency as the Base receiver.
- The current status on the bottom will change from Single to Fixed.

Set up communication -> Set up corrections (RTK by Internet, Wi-Fi, and Radio) -> set Antenna Height -> Set up basic Parameters






Now set up correction formats, antenna height, and basic parameters like in a GNSS base station.

5 Internal GSM

In Internal GSM mode, you need to set the data link as Internal GSM, Server, IP Port.




6 Basic Survey Functions



This section describes the basic survey functions of Geo Master, including point measurement, Topo survey, Auto survey, Static, PPK, staking, site calibration, and importing & exporting measured points.


6.1 Topo Survey

First, make a codelist before starting the TOPO Survey. To collect survey points, a codelist is mandatory.



- Click on Topo Survey-> enter point name- 
- You can quickly change the antenna height in the survey interface.
- Click  to change the map view.
- Measure the slant height upto the red-colored ring on the receiver housing.
- Measure the vertical height upto the bottom panel of the receiver housing.








6.2 Auto Survey

First make a codelist before starting an AUTO Survey like TOPO Survey. Auto survey supports automatic and continuous survey according to Time or Distance.



- Click on Auto Survey-> enter point name - 📍
- You can quickly change the antenna height in the survey interface.
- Click 📏 to change the map view.
- Measure the slant height upto the red-colored ring on the receiver housing.
- Measure the vertical height upto the bottom panel of the receiver housing.





6.3 Stake Points



Go into the Stake point interface, click to choose a point, and tap Stake. GEO Master provides a navigation map when staking points. If you are close enough to the target point, it will alarm you based on the alarm range you set.




6.4 PPK

PPK (post processing kinematic) is the unique function of the GEO master, which is used for post-processing dynamic measurements. It also needs two receivers to work together; one to work as a base to record static data, and another one to work as a rover, as shown below.



Click PPK -> enter initialization time and occupation time -> click Start Record button to begin PPK logging






6.5 Static

Firstly, click on Static -> enter File name -> enter time to which we want to log data -> start recording Static/Raw Data.



7 Site Calibration

Site calibration is commonly needed once in one project. For this, there should be more than two points and less than eight points. Select Site Calibration -> click add button -> add at least three points -> Compute and find the result.



< Site Calibration

Site Calibration

Angle : -244.753657173

Scale : 0.468511306

σ H Residuals 0.378

σ V Residuals 1.901


Point_name	H Residuals	V Residuals
<input type="checkbox"/> Pt11	0.000	1.901
<input type="checkbox"/> Pt11	0.987	1.901
<input type="checkbox"/> Pt1	0.148	1.901

Add
Save
Compute

8 Area Calculation and COGO

To calculate the distance between two points and the area of a polygon,

Enter two points -> compute distance -> for area, enter at least three points and compute.




9 Data Export/Import

With the import/export functions, you can import and export any survey data, files, and stake points fluently.

9.1 Import

- Click Import in the project interface ->Click Path to add files.
- File format: supports *.csv, *.dxf .



9.2 Export

Tap Export to export survey points.

- File format: supports *.csv, *.dxf .
- The default export path is .../...../.....



10 Internal Radio Mode

The NAVIK 200 GNSS receiver supports transmitting & receiving correction data in internal radio mode. To conduct the RTK survey in internal radio mode requires:



A controller with software installed



An extension bar



Two units of NAVIK 200 GNSS receiver



Two whip antennas



A range pole with bracket



Tripod and Tribrach

More: Aim to improve the radius of the work field; we can change the base receiver's Whip Antenna to an External Antenna. And others do not need change.

- NAVIK 200 GNSS Receiver
- External Antenna

11 External Radio

The external radio mode can increase the RTK working distance, making it ideal for areas with dense construction or high signal interference. To set up external radio mode requires:

Base station

- An external radio
- An external power supply
- A long whip antenna
- Transmission cables
- An NAVIK 200 receiver
- Tripod and tribrach

Rover

- An NAVIK 200 receiver
- A Whip Antenna
- A controller with software installed
- range Pole with bracket

Warning and Caution

An absence of specific alerts does not mean that there are no safety risks involved. A Warning or Caution information is intended to reduce the risk of personal injury and/or equipment damage.

WARNING - A warning alerts you to a potential risk of serious injury to your person and/or damage to the equipment, because of improper operations or wrong settings of the equipment.

CAUTION - A caution alerts you to a possible risk of damage to the equipment and/or data loss.

Warranty Notice

We are not responsible for damages or tempered devices. Apogee GNSS Pvt. Ltd. does not warranty the disassembled devices.

Copyright Notice

This is the V1.0 (Feb, 2022) revision of the NAVIK 200 GNSS Receiver User Guide. It cannot be copied or translated into any language without the written permission of Apogee GNSS Pvt. Ltd.

Technical Assistance

If you have any questions and can't find the answer in this manual,

please contact your local dealer. Alternatively, request technical support either through email or through the website.

Safety Information

Before using the receiver, please make sure that you have read and understood this user guide, as well as the safety requirements.

- Connect your devices strictly based on this user guide.
- Install the GNSS receiver in a location that minimizes vibration and moisture.
- Avoid falling to the ground or colliding with other items.
- Do not rotate 7-pin LEMO port.
- Do not cover the radio; keep a sound ventilation environment.
- To reduce radiation, please keep away from any radio station.
- Take lightning protection measures when installing antennas.
- Do not use damaged cables.

Use and Care

The receiver can withstand the treatment that typically occurs in the field. However, the receiver is high-precision electronic equipment and should be treated with reasonable care.



@APOGEE GNSS PVT.LTD. (AGPL)

Follow our social media & official website for more information

Corporate office

A- 67, Sector 63
Noida, 201307, Uttar Pradesh
Website: <https://www.apogeegnss.com>
Email: support@apogeegnss.com

